



## INSTALLATION INSTRUCTIONS:

- 1. REMOVE EXISTING LENS HOUSING FROM DOME LIGHT BY GRASPING OUTER RING AND PULLING FIRMLY.
- 2. REMOVE SNAP RING, SPRING WASHER AND LENS.
- 3. INSERT LENS 723-1301-0100-99 WITH PATTERNED SIDE FACING OUT.
- 4. INSERT FILTER 561-9230-0100-99
- 5. INSTALL SPRING WASHER AND SNAP RING SO THAT IT SNAPS INTO GROOVE INSIDE THE HOUSING.
- 6. INSTALL O-RINGS ORG-0046 ONE AT A TIME. PRESS THEM FLUSH ONTO THE SNAP RING AND EACH OTHER. THESE WILL BLOCK THE LIGHT FROM ESCAPING THE HOUSING THROUGH THE SIDES.
- 7. PRESS LENS HOUSING ASSEMBLY BACK INTO THE DOME LIGHT UNTIL SNAPS IN PLACE.

BREAK SHARP EDGES  UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES  TOLERANCES ARE: FRACTIONS DECIMAL ANGLES ±1/8° . X ±.050 ±2°XX ±.030XXX ±.010	DESIGNED CLB	DATE 9/22/11	GENEVA				
	DRAWN	DATE		A	/LATI	6	
	CHECKED	DATE	Title NV/IC F		INIOTALI		10N
	APPROVED CLB	DATE 9/22/11	NVIS FILTER INSTALLATION P112-NVIS				
THIS DOCUMENT INCLUDES INFORMATION PROPRIETARY TO GENEVA AVIATION AND SHALL NOT BE USED OR DUPLICATED BY ANYONE WITHOUT THE WRITTEN PERMISSION OF GENEVA AVIATION, INC.			Drawing Number G12890				REV
			Pro No: GA129	SIZE <b>B</b>	Scale:NONE	She	et of